

**FUEL
TABLE OF CONTENTS**

CHAPTER 12

	Page
TABLE OF CONTENTS	12-00-1
DESCRIPTION	
General	12-10-1
Fuel Specifications	12-10-2
Fuel System Synoptic Page	12-10-3
AC Boost Pumps	12-10-3
DC Auxiliary Pumps	12-10-3
Aft Transfer Pumps	12-10-4
Centre Transfer Pumps	12-10-4
Fuel Control Panel	12-10-4
Fuel Tanks	12-10-5
Service Points	12-10-5
Vent System	12-10-6
Vent System Schematic	12-10-6
Transfer System	12-10-7
Centre Transfer	12-10-8
Wing Transfer	12-10-8
Auto Wing Transfer	12-10-8
Manual Wing Transfer	12-10-9
Crossfeed	12-10-9
Aft Transfer	12-10-11
Engine Feed System	12-10-13
Engine Feed System Indication	12-10-14
APU Fuel Feed	12-10-15
Fuel Quantity and Indication	12-10-16
Flight Management Display	12-10-17
Refuel/Defuel System	12-10-18
Refuel/Defuel Panel	12-10-19
Normal Fuel Loading	12-10-20
Gravity Refueling	12-10-21
Pressure Refueling	12-10-21
Manual Refueling	12-10-22
Suction Defueling	12-10-22
Pressure Defueling	12-10-22
Fault Reporting	12-10-23
Error Messages	12-10-23
INHIBIT	12-10-23

**FUEL
TABLE OF CONTENTS**


	Page
DESCRIPTION	
FULL	12-10-23
LOAD ERROR	12-10-23
IMBAL	12-10-23
REPEATER	12-10-23
FAILED	12-10-24
FMQGC – FAILURE	12-10-24
Refueling Distribution	12-10-24
Fuel Re-Circulation System (On airplanes with SB 700-28-034 incorporated)	12-10-24
Refuel/Defuel Schematic	12-10-27
Fuel Filters, Quantity and Temperature Readouts	12-10-28
Fuel Pump Displays	12-10-29
Fuel Shut-off Displays	12-10-30
Fuel Synoptic Page Symbols	12-10-31
EICAS Philosophy	12-10-31
Fuel Management Quantity Gauging System (FMQGS)	12-10-31
FMQGC Schematic	12-10-32
EICAS Messages	12-10-33
EMS CIRCUIT PROTECTION	
CB – Fuel System	12-20-1

GENERAL

Fuel is contained in a wet wing box structure, which is sealed to form three main separate wing tanks (left wing, right wing and centre wing) and a smaller quantity of fuel is carried in a separate aft fuselage tank. The tanks are vented to atmosphere and slightly pressurized by an air scoop located on the lower surface of each wing. A scavenge pump purges fuel from the vent lines and a climb vent, located in each main wing tank, provides ventilation when the airplane is in a nose up attitude.

Each engine is supplied with fuel from its respective feed tank which contains two alternating current or AC primary pumps and one Direct Current (DC) back up electrical boost pumps. The transfer system maintains the feed tanks full during all attitudes and provides automatic transfer of fuel from the centre tank and aft tanks to the main wing tanks.

Lateral balance between left and right main tanks is controlled automatically by the Fuel Management and Quantity Gauging Computer (FMQGC) or manually through switch selections in the flight compartment.



GF1210_001

Flight deck control is provided on the overhead panel and fuel quantity and warnings are displayed on EICAS.

A single point pressure refuel/defuel adapter is provided which is connected to a manifold containing shut-off valves. Pressure refueling can be done either automatically or manually. Gravity filling is provided for each wing tank.

GENERAL (CONT'D)

A dual channel FMQGC continuously monitors the following:

- Fuel quantity indicating.
- Left, right engine and APU feed.
- Wing to wing balance (wing XFER).
- Centre tank transfer.
- AFT tank fuel transfer.
- Refuel/defuel.

Any fault detected by the fuel system computer is annunciated on Engine Indication and Crew Alerting System (EICAS), in the form of a visual and/or aural alert and/or maintenance diagnostics.

FUEL SPECIFICATIONS


For information on fuel additives, temperature limitations and approved fuels, refer to Flight Crew Operating Manual (FCOM) CSP 700–6 Vol 1 – LIMITATIONS Chapter.

Fuel remaining in a tank when the appropriate fuel quantity indicator reads zero is not usable. The figures below are approximate values only. Refer to the FCOM CSP 700–6 Vol 1 for exact tank and total fuel quantity.

Left main tank	14,900 lb	(6,757 Kg)
Right main tank	14,900 lb	(6,757 Kg)
Centre tank	11,000 lb	(4,989 Kg)
AFT tank	2,200 lb	(997 Kg)
Total	43,000 lb	(19,500 Kg)

FUEL SYSTEM SYNOPTIC PAGE

The FUEL synoptic page provides an overview of system status, as represented below with both left and right engines running and no transferring of fuel taking place.



GF1210_002

AC Boost Pumps

Two AC boost pumps, also referred to as primary boost pumps, are located in each feed tank. They normally supply fuel to the engines in all airplane ground and flight mode operations. Each pump is capable of maintaining an engine (fuel demand) in all modes of engine operation. The two pumps are continuously on, whenever the engine is operating and AC power is available. Both boost pumps (two on each side) may be inhibited by selection of one of the individual switches on the fuel control panel. The boost pumps are controlled automatically through the Alternating Current Power Centre (ACPC), when a fuel command is received.

DC Auxiliary Pumps

DC powered Auxiliary Pumps (AUX pumps) one in each feed tank, are used for engine and APU starting and wing to wing transferring of fuel when requested. The AUX pumps will come on automatically in support of engine feed in the event of an AC boost pump failure. During take-off and landing the pumps will also come on automatically with engines on and at least one of the following: flaps > 0°, landing gear down and in flight or low wing fuel condition (600 lbs each wing). Each AUX pump may be inhibited by selecting off a switch on the fuel control panel.

NOTE

When an AUX pump is used for wing transfer mode of operation and an AC pump fails, priority is given to the engine feed system and the automatic wing transfer operation will be inhibited.

The pumps are automatically controlled by the Secondary Power Distribution Assembly (SPDA).

FUEL SYSTEM SYNOPTIC PAGE (CONT'D)

Aft Transfer Pumps

Two aft transfer pumps and associated shut-off valves are used to transfer fuel from the aft fuel tanks to the wing tanks. Transfer is scheduled by the fuel computer or by a switch selection on the fuel control panel.

Centre Transfer Pumps

Two centre transfer pumps (controlled by the FMQGC) are used to transfer fuel from the centre tank to the main wing tank.

FUEL CONTROL PANEL

The fuel control panel is located on the overhead panel in the flight compartment. The fuel control panel defines the operational modes, component controls and component inhibits.

The fuel control panel has switches, which when selected, override the automatic control of certain components within the fuel system. Switch selections from this panel are sent to the ACPC. The ACPC will then control the system from the inputs received from the panel. The switch lamps come on in combination with certain EICAS messages, which represent the panel configuration or failure within a given system.

WING XFEED switch

- **AUTO** selection – Provides a means of transferring fuel from one wing to the other. Controlled by the FMQGC.
- **<- or ->** selection – A left to right or a right to left selection, provides a means of transferring fuel (in the direction of the arrow) from one wing tank to the other.
- **OFF** selection – Provides a method of inhibiting wing to wing transfer.

AUX PUMP switch


- **OFF** light – Indicates that the right auxiliary pump has been disarmed. The left AUX PUMP has similar logic.

XFEED SOV switch

- **FAIL** light – Will come on when the valve does not go to the commanded position.
- **OPEN** light – When the switch is selected, the crossfeed valve opens and interconnects the engine feed lines.

PRI PUMPS Switch

- **OFF** light – Indicates that both left wing primary pumps have been disarmed. The right PRI PUMPS switch has similar logic.



RECIRC switch (If installed)

- **ON** light – Indicates that the FRTT valve is open when commanded by flight crew.

AFT XFER Switch

- **AUTO** selection – Provides a means of transferring fuel from the aft tank to the wing tank. Controlled by the FMQGC.
- **ON** selection – Provides a manual method of controlling the transfer schedule.
- **OFF** selection – Inhibits the forward/aft transfer of fuel.


GF1210_003

FUEL TANKS

All fuel is carried in three integral tanks (left wing, right wing and centre wing) and a smaller aft fuselage tank (contained in a structurally enclosed bladder).

The inboard section of each wing is designated as a feed tank, from which each engine draws its fuel. Fuel flows from the outboard sections of each wing tank, into the feed tank (by gravity), through swing check valves in the baffles of each main tank. The check valves allow fuel flow in the inboard direction only. This will restrict large fuel movements and limit centre of gravity shifts in airplane changes of attitude. Fuel is also transferred into the feed tanks from the centre wing and aft fuselage tanks by the transfer system.

SERVICE POINTS



GF1210_004

All tanks have flush self-closing water drain valves, installed at various low points, to permit draining of any accumulated water or residual fuel. They are located at the low point of each wing. Three gravity fill caps are provided for wing and centre tank gravity refueling.


VENT SYSTEM

An open vent (no float valves or flame arrestors) system is used to control the pressure in the fuel tanks. It consists of vent line tubing and ram air outlets (scoops) to ensure adequate venting of all fuel tanks. The vent lines connect the two air scoops to the fuel tanks and the fuel tanks to each other. The lines are drained of fuel which is returned to the feed tanks during operation. The low point of the main vent line is continuously scavenged by a jet pump.

The vent line distribution is to a high point in the fuselage, preventing fuel from reaching either of the two ram outlets and spilling overboard. If any fuel passes the high point, it is collected by the surge box and is drained back to the tank before it reaches the outlet. Each surge box vent line tubing runs vertically along the fuselage side wall and is coupled to the wing, centre and aft tanks.

The vent system is fully redundant such that any single blockage does not affect the venting capability.

VENT SYSTEM SCHEMATIC



GF1210_005

Relief valves are used to protect the tanks from over pressurization, in the case of failure of the vent system and/or refuel shut off valve. They are located in the wing, centre and aft tanks. The aft tank relief valve has a similar function as the centre and wing tank relief system, but also incorporates a negative pressure relief feature which can activate in an emergency descent.

TRANSFER SYSTEM

Fuel contained in the centre tank and the aft fuselage tank cannot be fed directly to the engine, but must be first delivered to the feed tanks by the transfer pumps. The normal sequence of fuel usage is to transfer centre tank fuel into the wings as required to keep the wings full during climb and cruise while holding the aft fuselage tank full.

After depletion of centre tank fuel quantity, fuel continues to be burned from the wing tanks until 5500 lbs of fuel remains in either wing tank, at which point, transfer of fuel from the aft tank to the feed tanks is initiated. The transfer from the aft tank is then continuous until the aft tank is empty. When the aft fuselage tank fuel is depleted, no further transfer of fuel is required, since all remaining fuel is contained in the wing tanks.

Effectivity:

- *Airplanes 9002, 9004 thru 9082 **not incorporating** Service Bulletin:*
 - *SB 700-28-033, Fuel Management and Quantity Gauging System (FMQGS) – FMQGS Computer Change to Part No. GP546-1501-5.*

After depletion of centre tank fuel quantity, fuel continues to be burned from the wing tanks until 4000 lbs of fuel remains in either wing tank, at which point, transfer of fuel from the aft tank to the feed tanks is initiated. The transfer from the aft tank is then continuous until the aft tank is empty. When the aft fuselage tank fuel is depleted, no further transfer of fuel is required, since all remaining fuel is contained in the wing tanks.


Control of fuel transfer from the centre and aft tanks is normally under control of the fuel computer. Manual override is provided to command transfer of aft tank fuel into the feed tanks via the fuel control panel. There is no manual override for the centre tank transfer system.

TRANSFER SYSTEM (CONT'D)

Centre Transfer

Fuel transfer from the centre tank to wing tank is completely automatic through the control of the FMQGC. The FMQGC monitors the fuel level and quantities in the wing tank (using fuel probes, compensators, densitometers and temperature sensors) to control fuel transfer from the centre tank to the wing tanks. Fuel will be transferred from the centre tank and delivered to the wing feed tanks, through the use of two centre transfer pumps.

The FMQGC will start the applicable centre transfer pump(s) when each individual wing tank reaches approximately 93% of its fuel tank capacity. The FMQGC will automatically stop the centre transfer pump(s) when the respective wing tank reaches greater than 97% of its fuel tank capacity.



GF1210_006

The FUEL synoptic page represents the centre tank transfer operation with both engines running.

Wing Transfer

The wing transfer system permits fuel to be pumped from either side of the airplane to the other, using the DC auxiliary pumps and motor operated shut-off valves.

The wing transfer system provides a means of correcting lateral fuel imbalance. It may be used in automatic mode via FMQGC or manual mode as selected by the cockpit fuel control panel. Fuel imbalance at a predetermined value will be annunciated on the EICAS display in the form of a caution message.

Auto Wing Transfer

In the wing transfer automatic mode, the FMQGC will correct lateral fuel imbalances of 400 pounds on ground and in flight. The FMQGC will control and operate the DC auxiliary pumps and wing transfer SOV's as necessary to pump fuel from the feed tank into the opposite wing. Once commanded on, the wing transfer system remains on until lateral fuel imbalance is ± 50 pounds.

In the event of a centre tank transfer pump failure, fuel will be transferred from the operating centre tank transfer pump to its respective wing tank. The automatic wing transfer system will maintain lateral fuel balance, to ensure that fuel contained in the centre tank is available to both engines.

TRANSFER SYSTEM (CONT'D)

Manual Wing Transfer



In manual mode, the wing transfer system is controlled using the fuel WING XFER switch. Once selected, the wing fuel transfer continues until the WING XFER switch is selected off on the fuel control panel.

DC Auxiliary Pump

In wing transfer demand, commanded on by the FMQGC.

Wing Transfer Shut-Off Valve

Commanded on by the FMQGC or manually by the switch on the fuel control panel.



GF1210_007

The FUEL synoptic page represents the left to right wing transfer mode of operation with both engines running.

Crossfeed

The crossfeed system permits interconnection between the left and right engine feed lines, using a shut-off valve. This will enable both engines to be fed by either feed tank or alternatively enable a single engine to be supplied from both feed tanks.


For normal airplane operations, the crossfeed shut-off valve is closed, isolating the feed lines and ensuring that each engine is supplied fuel only from its own side of the airplane. Opening the crossfeed shut-off valve interconnects the feed lines, enabling fuel to flow from one engine feed line to the other.

No automatic means of controlling the crossfeed SOV is provided and selection has to be made using the XFEED SOV switch on the fuel control panel.

TRANSFER SYSTEM (CONT'D)

Crossfeed (Cont'd)

In single engine operating mode with the crossfeed shut-off valve opened, fuel flows from both feed tanks via the AC primary pumps to the single engine and fuel flow rates from both sides of the airplane are considered essentially the same. Therefore the airplane can be flown indefinitely without developing any significant lateral fuel imbalance.



GF1210_008

The FUEL synoptic page represents the fuel crossfeed mode of operation, with the crossfeed shut-off valve selected open, left engine shut down, left engine feed shut-off valve closed and the right engine running.

A secondary use of the crossfeed system (as a back-up to the wing transfer system) is to provide means of correcting lateral C of G imbalances, by temporarily inhibiting the flow fuel from the light side of the airplane. Fuel will then be supplied to both engines from the “heavy” side until lateral fuel imbalance is within desired limits.



The possibility of engine flameout could occur, if the crossfeed valve is not opened prior to inhibiting the fuel pumps.

In this operating mode, the crossfeed valve is selected open via the “XFEED SOV” switch on the fuel control panel. The fuel pumps on the light side of the airplane are turned off, using the applicable AUX PUMP and PRI PUMP switches. Fuel will then be supplied from the heavy side of the airplane only, thereby correcting the lateral fuel imbalance. Crossfeed continues in this mode until the crew deselects the switches after lateral balance is achieved.


NOTE

It is important that the crew monitor system operation in this mode, since crossfeed will continue until manually deselected.

TRANSFER SYSTEM (CONT'D)

Crossfeed (Cont'd)

In the event that a lateral fuel imbalance occurs outside design limits, it will be annunciated on EICAS, prompting the crew to take action.



The FUEL synoptic page represents the fuel crossfeed mode (back-up) of operation. The system is shown with the crossfeed shut-off valve selected open, left auxiliary pump inhibited, left forward and aft boost pumps inhibited and both engines running.

Aft Transfer

Fuel contained in the aft tank is retained until late in the flight, in order to maintain a favorable aft centre of gravity (C of G).

The aft transfer schedule is normally controlled automatically by the FMQGC. Fuel can also be transferred or inhibited manually from aft tank to wing tank, using the AFT XFER switch on the fuel control panel, if desired.


Aft transferring of fuel is achieved using the two AC boost pumps and two shut-off valves. Each of the two transfer pumps in the system has sufficient capacity to maintain the transfer schedule in the event of a failure of one of the pumps.

GF1210_010

TRANSFER SYSTEM (CONT'D)

Aft Transfer (Cont'd)

When the aft transfer system is commanded to operate, the aft tank refuel transfer valve and the aft transfer pump come on. Fuel is then pumped by the aft transfer pump into its respective feed tank.



Aft Transfer Pump

In the AUTO mode, the transfer schedule is controlled by the FMQGC. Manual mode ON or OFF transfers or inhibits fuel transfer to the wings.

GF1210_011

The FUEL synoptic page represents the fuel aft transfer mode of operation, with both engines running. The system is shown transferring fuel from the aft tanks to their respective wing tanks.

ENGINE FEED SYSTEM

Fuel is provided to each engine from the two AC boost pumps. In normal operation, both boost pumps are continuously on and provide all engine fuel flow once the engine is started. The AC pumps are located in the inboard section of each wing (feed tank) and each AC pump is powered by a separate bus.

Engine start capability and relight is provided by using the DC Auxiliary (AUX) pumps located in both feed tanks. These DC pumps will turn off as AC electrical power becomes available and the AC boost pumps are operating.

Loss of pressure at any AC boost pump causes the DC pump to come on, to provide a back up of the remaining boost pump. The DC pumps also come on automatically for take-off, based on flaps/slats position and weight on wheels logic.

The engine fuel burn schedule is automatically controlled by the FMQGC to ensure correct distribution for all airplane configurations.

The engine fuel burn sequence is as follows:

- Fuel from the wing tanks will burn first,
- When the wing tanks get below 93%, fuel transfers from the center tank to the wing tank until it is at or above 97%,
- When the center tank empties, fuel from the wing tanks continue to burn,
- When either wing tank reaches 5500 lb, fuel transfers from the aft tank,
- Once the aft tank is empty, the wing tanks will continue to burn the remaining fuel.

Effectivity:

- *Airplanes 9002, 9004 thru 9082 **not incorporating** Service Bulletin:*
 - *SB 700-28-033, Fuel Management and Quantity Gauging System (FMQGS) – FMQGS Computer Change to Part No. GP546-1501-5.*



The engine fuel burn sequence is as follows:

- Fuel from the wing tanks will burn first,
- When the wing tanks get below 93%, fuel transfers from the center tank to the wing tank until it is at or above 97%,
- When the center tank empties, wing tank continue to burn,
- When either wing tank reaches 4000 lb, fuel transfers from the aft tank,
- Once the aft tank is empty, the wing tanks will continue to burn the remaining fuel.

ENGINE FEED SYSTEM (CONT'D)


Engine Feed System Indication

The left FUEL synoptic display represents the engine starting mode of operation with the right DC pump running. In this scenario, the right engine is starting using the battery as the only source of electrical power, Auxiliary Power Unit (APU) and left engine are off. The right FUEL synoptic display represents the right engine on speed and electrical AC power established.



GF1210_012

The FUEL synoptic display below represents airplane configuration with the APU shut down, both engines on speed, AC pumps running and the DC pumps on standby.



GF1210_013

APU FUEL FEED

The APU start capability is normally provided by the DC AUX pump(s). The fuel supplied to the APU is taken from the right engine feed line. The APU can also be fed from the left engine feed line using the left DC AUX pump (powered by DC ESS bus) and opening the crossfeed shut-off valve. A motor operated fire shut-off valve is used in the APU feed line in order to isolate the flow of fuel to the APU in case of a fire or rotor burst.


The FUEL synoptic page top view represents the APU starting with the right DC pump running and battery power only as the single source of electrical power. In the lower view, the APU is fed from the right engine feed line using the AC pumps.

TOP VIEW

NOTE

APU start in progress, left and right engines are off.

APU – Green outline will be indicated when the APU is on speed.




APU FEED SHUT-OFF VALVE

GF1210_014

LOWER VIEW

NOTE

APU on speed, left and right engines on and AC electrics established.



GF1210_015

FUEL QUANTITY AND INDICATION

The fuel quantity gauging system is an ac-type capacitance system. Fuel quantity probes, compensators, densitometers, temperature sensors and high level detectors are inputs received by the FMQGC. The FMQGC uses this acquired data to compute the fuel quantity for each tank and total fuel quantity remaining on board the airplane.

The FMQGC outputs the computed individual fuel tank, total quantity and fuel temperature for EICAS display. The fuel system computer corrects for airplane pitch attitude and presents the corrected information of individual tank quantities and total fuel quantity displayed on EICAS.

Fuel Flow Readout

Indicates fuel flow in pounds per hour (PPH) to the respective engine.

Total Fuel Readout


Indicates total fuel quantity in pounds (lbs), of all the tanks.

- Green – Total fuel quantity is valid and in normal range.
- Amber – The fuel quantity is low.
- Dashed – Fuel quantity is not valid.

Fuel Quantity Readout (wing tank)

Indicates fuel quantity in the respective wing tank, in pounds (lbs).

- Green – Left and right tanks are balanced.
- Amber – A fuel quantity imbalance exists or applicable tank is less than 600 lbs (272 KG).
- Dashed – Fuel quantity is not valid



EICAS PRIMARY DISPLAY

Fuel Quantity Readout (center fuselage tank)

Indicates fuel quantity in the centre tank, in pounds (lbs).

- Green – Quantity is valid.
- Dashed – Fuel quantity is not valid.

Fuel Quantity Readout (aft tank)

Indicates fuel quantity in the aft tank, in pounds (lbs).

- Green – Quantity is valid.
- Amber – The aft tank fuel transfer is off schedule.
- Dashed – Fuel quantity is not valid.

GF1210_016

The FMQGS can display fuel quantity in either LB (standard) or KG (optional). The primary EICAS page displays fuel quantity in all fuel tanks and total fuel in the airplane.

FLIGHT MANAGEMENT DISPLAY

When both engines are started, the Fuel Management System (FMS) fuel quantity switches from Fuel Management Quantity Gauging System (FMQGS), to computed fuel quantity, based on fuel flow data from the engines and APU.

Compare Fuel Quantity
Displays when the gauge fuel quantity and the calculated FMS fuel quantity differs by more than 2%.







GF1210_017

Fuel quantity information to the FMS is used for monitoring and sensing, to assist in determining a fuel leak. When a fuel leak is detected, a crew alert ("MSG" on the primary flight display) will be displayed and a message will appear on the scratchpad of the FMS CDU.

REFUEL/DEFUEL SYSTEM

Pressure refueling/defueling operations are controlled from the refuel/defuel control panel. Pressure refueling can be accomplished in "MANUAL" or "AUTO" mode of operation.



IF INSTALLED

GF1210_018


Gravity filling via a filler point is also provided for the wing and centre wing tanks.

REFUEL/DEFUEL PANEL

LEFT/RIGHT/CTR/AFT/TOTAL
Displays the current fuel quantity in each tank and the total quantity in all tanks. Quantities are displayed in 50 lb (25 KG) increments.

PRESELECT TOTAL QTY DISPLAY
Displays the fuel quantity target for automatic refueling. Set in 100 lb (50 KG) increments.

PRESEL INCR/DECR
Increases or decreases the preselect quantity for AUTO refueling.



FUEL SOVs
Allows tanks to be refueled or defueled manually.

START-STOP/SOV TEST
• START – Initiates refueling.
• STOP/SOV TEST – Stops automatic refueling or enables testing of the refuel SOVs and circuitry during fueling.

AUTO MODE
• AUTO REFUEL – Enables automatic refueling.
• AUTO REFUEL – NO AFT – Enables automatic refueling and inhibits aft tank refueling.

MODE SELECTOR
• MANUAL REFUEL – Enables manual refueling using the fuel SOVs.
• MANUAL DEFUEL – Enables manual defueling using the fuel SOVs.

OFF POSITION
• OFF – Removes power from the panel.

REFUEL/DEFUEL PANEL (CONT'D)

LEFT/RIGHT/CTR/AFT/TOTAL

Displays the current fuel quantity in each tank and the total quantity of all tanks. Quantities are displayed in 50 lb (25 KG) increments.

INCR/DECR


Increases or decreases the preselect quantity for AUTO refueling.

PRESELECT TOTAL QTY DISPLAY

Displays the fuel quantity target for automatic refueling. Set in 100 lb (50 KG) increments.

MASTER ON/OFF

Supplies power to the components required for fueling/defueling.



SHUT OFF TEST

When selected shuts off all valves to verify their operation. It also carries out a test of the high level sensors and circuitry in each tank during refueling.

MANUAL FUEL SOVs

Allows tanks to be refueled or defueled manually.

MODE SELECTOR

- REFUEL – Enables manual refueling.
- AUTO REFUEL – Enables automatic refueling.
- DEFUEL – Enables manual defueling.

START/STOP

- (for AUTO mode only)
- START – Starts automatic refueling.
 - STOP – Stops automatic refueling.

AFT ON/OFF

Enables or disables the automatic function of refueling the aft tank.

Normal Fuel Loading

The normal fuel loading is as follows:

- Wing tanks only if the required fuel load is equal to or less than the wing tank capacity.
- Wing tanks full and the remainder in the aft tank if the required fuel load is greater than the wing tank capacity, but less than or equal to the combined capacity of the wing and aft tanks.

GF1210_020

REFUEL/DEFUEL PANEL (CONT'D)


Normal Fuel Loading (Cont'd)

- Any fuel in excess of the combined capacity of the wing and aft tanks is placed in the centre tank.

NOTE

The left and right wing tank quantities must be within 400 lbs (181 KG) for normal fuel loading.

An additional switch position on the refuel/defuel panel allows auto refueling without adding fuel to the aft tank.



GF1210_021

If the aft tank fueling is inhibited by the switch then the refuel sequence is as follows:

- Wing tanks only if the required fuel load is equal to or less than the wing tank capacity.
- Wing tanks full and the remainder in the centre tank if the required fuel load is greater than the total wing capacity.

Gravity Refueling

The wing tanks may be refueled through over wing gravity fill adapters located on top of both left and right wings. It is not possible to completely fill either wing tank by gravity fueling, since the fill adapters are located outboard and below the maximum fuel level.

The centre tank may be refueled through a gravity fill adapter located on top of the right hand wing.

Gravity fueling of the aft tank is not provided.

Pressure Refueling

Pressure refueling is accomplished through the single point refuel/defuel adapter, located in the right hand wing root and is controlled by the refuel/defuel control panel. An optional duplicate refuel/defuel control panel can be installed in the flight compartment.

NOTE

A “SHUT-OFF TEST” must be carried out prior to all refueling operations.

If the test is successful a “SOV PASS” is displayed in the PRESEL window. If the test fails a “SOV FAIL” is displayed in the PRESEL window. “SOV FAIL” will be displayed in the tank window for the failed shut-off valve, alternating display of the tank quantity.

Pressure refueling may be performed in either “AUTOMATIC” or “MANUAL” mode. The airplane does not have a fuel jettison system.

REFUEL/DEFUEL PANEL (CONT'D)**Pressure Refueling (Cont'd)**

A preselect fuel quantity is used during automatic refueling of the airplane. This method will allow the airplane to be filled automatically to the desired fuel state selected.

NOTE

The preselect quantity is the desired final total fuel quantity in the tanks and not the quantity to be added.

In "AUTOMATIC" mode, fuel quantity added to each tank is automatically controlled by the FMQGC to give the correct distribution for the presented total quantity. Refueling flow is stopped when the total fuel quantity reaches the preselect quantity and the appropriate SOVs are commanded close.

Manual Refueling

In "MANUAL" mode, it permits the operator to select and control the fuel quantity to be added in each tank through the refuel/defuel panel. In this mode, the high level sensors automatically close the refuel/defuel SOVs if the maximum fuel level capacity is reached.

Suction Defueling

Suction defueling of the fuel tanks is carried out by applying suction (recommended pressure –8 psig) to the single point refuel/defuel adapter, using the refuel/defuel control panel.

- Wing Tank – Suction defueling of the wing tanks is accomplished by opening a valve which connects the refuel/defuel manifold to the engine feed line. This allows fuel to be drawn out of the tank through the suction defuel check valve in the feed tank.
- Centre Tank – The centre tank is defueled through the refuel/defuel shut-off valve.
- Aft Tank – The aft tank may be suction defueled using the same line and shut-off valve used for pressure refueling of the tank.

Pressure Defueling

Pressure defueling of the fuel tanks is accomplished through the fuel shut-off valves and single point adapter. Pressure defueling is identical to suction defueling, except that primary defueling flow is provided by the AC boost pumps or DC auxiliary pump in each feed tank.

NOTE

AC or DC electrical power is required to operate the airplane pumps for this procedure.

Direct pressure defueling of the wing tank is accomplished using the AC boost pumps or DC auxiliary pump in each feed tank.


Direct pressure defueling of the centre tank is not possible. Centre tank fuel may however be transferred to the wing tanks using the centre tank transfer pumps. From there, it may then be defueled via the wing tank.

Direct pressure defueling of the aft fuselage tank is not possible. Aft fuselage tank fuel may however be transferred to the wing tanks using the aft transfer pump. From the wing tank, it may then be defueled via the wing tank.

REFUEL/DEFUEL PANEL (CONT'D)

Fault Reporting

Fault reporting is in the form of error messages which will appear in the display windows of the refuel/defuel panel. In the event of a fuel computer failure, a “FMQGC” will be displayed in the TOTAL window and “FAILURE” in the PRESEL window. An example of fault reporting is illustrated below:



REPEATER

This indicates that two panels are powered on.


GF1210_022

If installed, the following information may be displayed in either or both quantity windows:



IMBALANCE

Displayed if an imbalance condition exists. The tank affected displays will alternate between IMBAL and tank quantity every two seconds.



GF1210_023

Error Messages

The following messages may be displayed on the refuel/defuel panel if a fault exists:

INHIBIT

In manual refuel or defuel mode, displayed when a tank switch is in the “OPEN” position. In pressure defuel mode, displayed when an engine is on (no fire handles pulled). In auto mode, displayed when the preselected fuel quantity is valid, airplane is in CAIMS maintenance mode or the SOV shut-off test fails.

FULL

Displayed when the high level shut-off has been activated.

LOAD ERROR

In auto refuel mode, displayed when an invalid fuel distribution is selected. Example, one tank contains more fuel than the target quantity assigned by the automatic distribution.

IMBAL

Displayed when a predetermined fuel quantity imbalance exists between the left and right wings.

REPEATER

Displayed in the PRESEL window of the external Refuel/Defuel Panel when two panels are powered “ON”. The panel located in the flight compartment is in control and the outside panel provides quantity display only.

Dashes (_ _ _ _ _) will be displayed for fuel quantity if the computed value is invalid.

REFUEL/DEFUEL PANEL (CONT'D)**FAILED**

Displayed in the PRESEL window if the Refuel/Defuel Panel is not functional.

FMQGC – FAILURE

FMQGC will be displayed in the TOTAL window and FAILURE in the PRESEL window if the Refuel/Defuel Panel is not communicating with the fuel computer.

Refueling Distribution

Refer to Refuel/Defuel Schematic for component location, recognition and operation.

All fuel tanks can be refueled either automatically (by the FMQGC) or manually (by the refuel/defuel panel). The recommended pressure is 50 psig. for pressure refueling.

A balance line in each tank is used during refueling to transfer fuel to the most outboard section of the wing.

The filling sequence of the wing compartment during pressure refueling is as follows:

- Cell 2 is filled directly by the refuel system, fuel flows inboard by gravity into:
- Cell 1, which is the inboard section including the feed tank. After inboard cells 1 and 2 are completely filled:
- Cell 3 is filled to capacity by overflow of cell 2 fuel through the balance tube connecting cells 2 and 3.

The aft and centre tanks will be refuelled simultaneously (automatically by the FMQGC) to maintain centre-of-gravity (C of G) limits.

High level sensors installed in each tank automatically close the refuel/defuel SOVs, if the maximum fuel level capacity is reached. Relief valves augment the normal vent system to prevent overpressure in case of overfilling a tank.

As with the wing tanks, automatic refueling of the centre tank is controlled by the FMQGC, with automatic shut-off commanded by the high level sensor. Automatic refueling of the aft tank is controlled by the FMQGC, with automatic shut-off commanded by the high level sensor.

Fuel Re-Circulation System (On airplanes with SB 700–28–034 incorporated)


The Fuel Re-Circulation system is designed to prevent the bulk fuel temperature from reaching the freezing point by recirculating heated fuel to the wing fuel tank. The system is operated through the L and R RECIRC switches on the Fuel Control panel.

Heat is generated by the engine oil cooling system. Cold fuel circulated through the Fuel Cooled Oil Cooler (FCOC) where the heat from the engine oil is transferred to the fuel. The Fuel Return To Tank (FRTT) valve allows the heated fuel to return to the wing fuel tank.

Each FRTT valve is electrically controlled and fuel pressure operated. The aircraft main fuel pump pressure is insufficient to activate the FRTT valve, thus the engine must be running for the FRTT valve to open.

REFUEL/DEFUEL PANEL (CONT'D)

Fuel Re-Circulation System (On airplanes with SB 700-28-034 incorporated) (Cont'd)



LEGEND

- Bulk Fuel Temperature
- Heated Fuel
- TS Temperature Sensor

GF1210_024

REFUEL/DEFUEL PANEL (CONT'D)

Fuel Re-Circulation System (On airplanes with SB 700–28–034 incorporated) (Cont'd)

The FRTT valves are powered by their dedicated circuit breakers on DC BUS 1 and 2.

Effectivity:

- Airplanes 9002 thru 9122 **not incorporating** Service Bulletin:
 - SB 700–28–039, Distribution – Permanent Wiring Configuration for the Fuel Re-Circulation System Following Power Source Change.

The FRTT valve circuit breakers are tied to the Refuel/Defuel Control Panel circuit breakers on the APU Battery Bus.

When the FRTT valve is open, fuel returns to the wing tank through the re-circulation line. The re-circulation line joins the aft tank transfer line. This slightly decreases the transfer rate of the aft tank to the feed tanks. Heated fuel is then distributed to the number 1 and 2 cell of the wing fuel tank. No fuel is distributed to the number 3 cell as it will have emptied before the local fuel temperature reaches -40°C ($^{\circ}\text{F}$). Both the re-circulation line and the aft tank transfer line are fitted with a check valve to prevent crossflow or fuel propagation due to a ruptured line.


The wing fuel tanks are fitted with many fuel temperature sensors; the left wing has two and the right wing has three. During normal operation (with the Fuel Re-Circulation selected OFF), the Fuel Management and Quantity Gauging System (FMQGS) computer reads all temperature sensors but will display only the lowest temperature. When the Fuel Re-Circulation system is selected ON, the FMQGS computer reads the inboard temperature sensor as it will be the one who reads the highest temperature. This logic is also used to determine the credibility of a failed temperature sensor in order to display the FUEL TEMP SENSOR FAIL caution message. In the event that only one side has been selected ON, the temperature displayed on the OFF side will be the lowest among all submerged temperature sensors of that side.

Operation of the Fuel Re-Circulation System is allowed only during cruise flight above 34,000 feet to ensure an additional safety margin in case of a main fuel pump failure. Wide Cut Fuel operations are limited to 13,000 feet until the bulk fuel temperature is below 15°C .

Display of system status is provided through EICAS messages. A L (R) FUEL RECIRC FAIL caution message will be displayed on the EICAS status page when the FRTT valve is not in the commanded or allowed position. Finally, the L (R) FUEL RECIRC ON status message will be displayed when the system operates properly and within specification.

The FUEL HI TEMP caution message is posted when the bulkhead fuel temperature exceeds 43°C when the Fuel Re-circulation System is inoperative. To prevent the system from operating above the freezing level, the set point has been reduced to 0°C when the system is selected on.

REFUEL/DEFUEL SCHEMATIC



LEGEND

Fuel distribution lines

- Left main refuel —
- Right main refuel —
- Centre refuel/defuel —
- Aft refuel/defuel and main defuel —

GF1210_025

FUEL FILTERS, QUANTITY AND TEMPERATURE READOUTS

Wing Fuel Quantity

Indicates fuel quantity in the respective wing tank, in pounds (lbs)

Fuel Quantity Readout (Centre Fuselage Tank)

Indicates fuel quantity in the centre tank, in pounds (lbs).

Total Fuel Quantity

Indicates fuel quantity in all fuel tanks, in pounds (lbs).

Fuel Used Quantity Readout

Indicates fuel quantity burned.

Engine Inlet Fuel Temperature

- Green – Engine fuel temperature is $\geq 5^{\circ}\text{C}$.
- Amber – Engine fuel temperature is $< 5^{\circ}\text{C}$.


Bulk Fuel Temperature Readout

- Green – Temperature of fuel in tanks is between -35°C and $+42^{\circ}\text{C}$.
- Amber – Temperature of fuel in tanks is lower than -35°C or greater than $+42^{\circ}\text{C}$.

On airplanes with SB 700-28-034 incorporated:

If Fuel Re-Circulation system is On:

- Green – Temperature of fuel in tanks is between -35°C and 0°C .
- Amber – Temperature of fuel in tanks is lower than -35°C or greater than 0°C .



Fuel Quantity Readout (aft tank)

Indicates fuel quantity in the aft tank, in pounds (lbs).

Fuel Filter

- Green – Indicates normal fuel flow through the filter.
- Amber – Fuel pressure drop exists across the filter.

Fuel Filter Flow Line

- Green – Indicates normal fuel flow to the engine.
- Amber – Fuel pressure drop exists across the filter, flow line from the filter to the engine turns amber.

GF1210_026

FUEL PUMP DISPLAYS

L or R DC Auxiliary Pumps


- ON – For engine starting, take-off and landing, primary pump failure and wing transfer of fuel.

NOTE: The AUX PUMP cannot be used to support the engine feed system and wing transfer at the same time.

- OFF – When commanded by the switch on the Fuel Control Panel or when both primary pumps are on.

Centre Transfer Pumps

Controlled by the FMQGC and transfers centre tank fuel to the wing tanks.



L or R AC Boost Pumps

- ON – At all times with the engines running.
- OFF – When commanded by the switch on the Fuel Control Panel.

Aft Transfer Pumps

- ON – When requested by the computer or selected on the Fuel Control Panel.
- OFF – When commanded by the switch on the Fuel Control Panel or when commanded by the FMQGC in AUTO mode.

GF1210_027

FUEL SHUT-OFF DISPLAYS

Wing Transfer SOV


Controlled by the FMQGC or the WING XFER switch on the fuel control panel.

Fuel Crossfeed SOV

Controlled by the switch on the Fuel Control Panel. It is used to interconnect the engine feed lines.

Engine Feed Shut-Off Valve

- Activated by the engine run switches on the throttle quadrant.
- Applicable engine FIRE DISCH handle.



Aft Tank Transfer Valve

Controlled by the FMQGC or the AFT XFER switch on the fuel control panel.

APU Feed Shut-Off Valve


- Activated by the RUN position switch on the APU control panel.
- Also controlled by the APU FIRE DISCH handle.

GF1210_028

FUEL SYNOPTIC PAGE SYMBOLS

The following represents the EICAS symbols and flow line logic for the fuel synoptic page. The symbols are shown in serviceable and failure conditions.

EICAS Philosophy




GF1210_029

FUEL MANAGEMENT QUANTITY GAUGING SYSTEM (FMQGS)

The FMQGS consists of a dual channel computer with BITE, utilizing capacitance type probes in each tank to continuously measure the quantity of usable fuel. The fuel computer performs all digital processing related to the system control and indication and performs computations associated with fuel gauging system requirements. The following schematic represents inputs and outputs of various components and systems operations.

FMQGC SCHEMATIC



GF1210_030

EICAS MESSAGES

L-R PRI FUEL PUMPS

Indicates that the forward and aft primary AC pumps on the affected side have failed to operate when requested.

WING TO CTR LEAK

Indicates that the fuel level in the centre tank has increased by 600 lbs or more.

-> FUEL XFER FAIL

Transfer from the left wing to the right wing has been requested and failed.

<- FUEL XFER FAIL

Transfer from right wing to left wing has been requested and failed.

<- FUEL XFER ON

Indicates that fuel is being transferred from the right wing tank to the left wing unrequested.

FUEL TEMP SENSOR

On ground, indicates that a fuel temperature sensor is failed. With flaps deployed, will be posted only if the failure requires corrective action.

FUEL IMBALANCE

Indicates that a fuel quantity imbalance exists between the left and right wing tanks of:

- More than 1100 lbs (499 KG) in flight.
- Between 600 lbs (272 KG) and 1100 lbs (499 KG) on ground or in Take-off / Approach configuration.

FUEL COMPUTR FAIL

Indicates that both channels of the fuel system computer have failed.

FUEL UNIT MISMATCH

The refuel/defuel panel and EICAS indications are correct but in different units of measurements.

AFT XFER OFF SCHED

Indicates that fuel transfer from the aft tanks to the wings is unable to keep pace with the optimum aft transfer schedule.

-> FUEL XFER ON


Indicates that fuel is being transferred from the left wing tank to the right wing unrequested.

L-R FUEL RECIRC FAIL

Indicates that the FRTT valve is not in the commanded or allowed position.

On airplanes with SB 700-28-036 incorporated:

Indicates that the FRTT valve is not in the commanded position.



FUEL LO QTY

Indicates fuel in the left or right wing tank is less than 600 lbs (272 KG).

GF1210_031

EICAS MESSAGES (CONT'D)

APU FUEL SOV

Indicates that the APU fuel shut-off valve has failed.

AFT XFER FAIL

Both left and right aft transfer components have failed to operate when requested. Aft tank fuel is no longer available.

L-R ENG FUEL SOV

Indicates that the engine fuel shut-off valve on the affected side is not in its commanded state.

CTR FUEL XFER FAIL


Indicates that both left and right centre tank pumps have failed to operate when requested.

WING FUEL HI TEMP

Indicates that the left or right wing fuel bulk temperature is greater than 42°C.

WING FUEL LO TEMP

Indicates that either the left or right wing fuel bulk temperature is at or below -35°C.



On airplanes with SB 700-28-034 incorporated:

If Fuel Re-Circulation system is On:
Indicates that the left or right wing fuel bulk temperature is greater than 0°C.


If Fuel Re-Circulation system is Off:
Indicates that the left or right wing fuel bulk temperature is greater than 42°C.

L-R WING FULL

Indicates that fuel quantity in the affected wing tank has exceeded its maximum allowable value.


GF1210_032

EICAS MESSAGES (CONT'D)



GF1210_033

EICAS MESSAGES (CONT'D)




GF1210_034

FUEL

EMS CIRCUIT PROTECTION

CB - FUEL SYSTEM



CB - FUEL SYSTEM 1/6		
→ XFER SOV C	DC ESS	IN
→ XFER SOV O	DC ESS	IN
← XFER SOV C	BATT	IN
← XFER SOV O	BATT	IN
AFT TANK L PUMP	AC 2	IN
AFT TANK L SOV C	DC 1	IN

CB - FUEL SYSTEM 2/6		
AFT TANK L SOV O	DC 1	IN
AFT TANK R PUMP	AC 3	IN
AFT TANK R SOV C	DC 2	IN
AFT TANK R SOV O	DC 2	IN
APU FIRE SOV	DC EMER DCPC	IN
FUEL COMPUTR CH A	BATT	IN

CB - FUEL SYSTEM 3/6		
FUEL COMPUTR CH B	DC ESS	IN
FUEL R/D CH A	APU BATT ASCA	IN
FUEL R/D CH B	APU BATT ASCA	IN
L AFT PRI PUMP	AC 1	IN
L AUX PUMP	DC ESS	IN
L CTR XFER PUMP	AC 1	IN

CB - FUEL SYSTEM 4/6		
L ENG FUEL SOV	DC EMER DCPC	IN
L FUEL RECIRC VLV	DC 1	IN
L FWD PRI PUMP	AC 2	IN
R AFT PRI PUMP	AC 4	IN
R AUX PUMP	BATT	IN
R CTR XFER PUMP	AC 4	IN

CB - FUEL SYSTEM 5/6		
R ENG FUEL SOV	DC EMER DCPC	IN
R FUEL RECIRC VLV	DC 2	IN
R FWD PRI PUMP	AC 3	IN
R/D MOTOR VALVES	APU BATT ASCA	IN
R/D PANEL COCKPIT	APU BATT ASCA	IN
R/D PANEL EXT	APU BATT ASCA	IN

CB - FUEL SYSTEM 6/6		
R/D SOL VALVES	APU BATT ASCA	IN
XFEED SOV C	BATT	IN
XFEED SOV O	BATT	IN


GF1220_001

FUEL EMS CIRCUIT PROTECTION

CB - FUEL SYSTEM (CONT'D)

Effectivity:

- Airplanes 9002 thru 9122 **not incorporating** Service Bulletin:
 - SB 700-24-045, AC and DC Power Distribution – Unit Change and Activation of Build 4 Electrical System.



<p>CB - FUEL SYSTEM 1/8</p> <p>→ XFER SOV C DC ESS IN</p> <p>→ XFER SOV O DC ESS IN</p> <p>← XFER SOV C BATT IN</p> <p>← XFER SOV O BATT IN</p> <p>AFT TANK L PUMP AC 2 IN</p> <p>AFT TANK L SOV C DC 1 IN</p>	<p>CB - FUEL SYSTEM 4/8</p> <p>L ENG FUEL SOV DC EMER DCPC IN</p> <p>L FWD PRI PUMP AC 2 IN</p> <p>L RECIRC SOV 1 C DC 1 IN</p> <p>L RECIRC SOV 1 O DC 1 IN</p> <p>L RECIRC SOV 2 C DC 1 IN</p> <p>L RECIRC SOV 2 O DC 1 IN</p>	<p>CB - FUEL SYSTEM 7/8</p> <p>R RECIRC SOV 3 O DC 2 IN</p> <p>R/D MOTOR VALVES APU BATT ASCA IN</p> <p>R/D PANEL COCKPIT APU BATT ASCA IN</p> <p>R/D PANEL EXT APU BATT ASCA IN</p> <p>R/D SOL VALVES APU BATT ASCA IN</p> <p>XFEED SOV C BATT IN</p>
<p>CB - FUEL SYSTEM 2/8</p> <p>AFT TANK L SOV O DC 1 IN</p> <p>AFT TANK R PUMP AC 3 IN</p> <p>AFT TANK R SOV C DC 2 IN</p> <p>AFT TANK R SOV O DC 2 IN</p> <p>APU FIRE SOV DC EMER DCPC IN</p> <p>FUEL COMPUTR CH A BATT IN</p>	<p>CB - FUEL SYSTEM 5/8</p> <p>L RECIRC SOV 3 C DC 1 IN</p> <p>L RECIRC SOV 3 O DC 1 IN</p> <p>R AFT PRI PUMP AC 4 IN</p> <p>R AUX PUMP BATT IN</p> <p>R CTR XFER PUMP AC 4 IN</p> <p>R ENG FUEL SOV DC EMER DCPC IN</p>	<p>CB - FUEL SYSTEM 8/8</p> <p>XFEED SOV O BATT IN</p>
<p>CB - FUEL SYSTEM 3/8</p> <p>FUEL COMPUTR CH B DC ESS IN</p> <p>FUEL R/D CH A APU BATT ASCA IN</p> <p>FUEL R/D CH B APU BATT ASCA IN</p> <p>L AFT PRI PUMP AC 1 IN</p> <p>L AUX PUMP DC ESS IN</p> <p>L CTR XFER PUMP AC 1 IN</p>	<p>CB - FUEL SYSTEM 6/8</p> <p>R FWD PRI PUMP AC 3 IN</p> <p>R RECIRC SOV 1 C DC 2 IN</p> <p>R RECIRC SOV 1 O DC 2 IN</p> <p>R RECIRC SOV 2 C DC 2 IN</p> <p>R RECIRC SOV 2 O DC 2 IN</p> <p>R RECIRC SOV 3 C DC 2 IN</p>	

GF1220_002