

# SEQUENCE

- i** Various **Smoke Sources**
- i** Existing Procedures
- i** Smoke **Procedure**
- i** Smoke **Removal**
- i** Conclusion

## VARIOUS SMOKE SOURCES

- CARGO
- LAVATORY
- CREW REST COMPARTMENT (A330/A340)

Easy to Identify

- AVIONICS
- AIR COND
- CABIN EQUIPMENT

Hard to Identify

# EXISTING PROCEDURES

## Easy to Identify

Supported by **ECAM**  
Procedure

Always the same process:

**Isolate** (close door / hatch, close isolation valve...)

**Extinguish** (automatic system or manual)

## Hard to Identify

Supported by **ECAM** or **Paper**  
procedures

More **difficult to locate** and to  
treat

Process depends on the  
situation

## EXISTING PROCEDURES

### Easy to Identify

Supported by **ECAM**  
Procedure

Always the same process:

**Isolate** (close door / hatch, close isolation valve...)

**Extinguish** (automatic system or manual)

### Hard to Identify

Supported by **ECAM** or **Paper**  
procedures


More **difficult to locate** and to  
treat

Process depends on the  
situation

In all cases, application of the  
**SMOKE REMOVAL PROCEDURE** may be necessary.

# EXISTING PROCEDURES


When **ECAM supported** : Carry out **ECAM actions**



When **not supported** by ECAM or ... **ECAM not readable**


Refer to : **SMOKE /AVNCS SMOKE**

**paper procedure**



# SMOKE PROCEDURE LAYOUT

In the QRH, the **SMOKE REMOVAL** procedure is facing the **SMOKE** procedure.





# SMOKE PROCEDURE LAYOUT

**Standard actions:**  
**must be applied** in all cases of smoke.

SMOKE/FUMES/AVNCS SMOKE	
	<b>LAND ASAP</b>
	<b>IF PERCEPTIBLE SMOKE APPLY IMMEDIATELY :</b>
	- BLOWER ..... OVRD
	- EXTRACT ..... OVRD
R	- CAB FANS ..... OFF
	- GALLEY ..... OFF
R	- SIGNS ..... ON
	- CKPT/CABIN COM ..... ESTABLISH
R	● <b>IF REQUIRED :</b>
R	- CREW OXY MASKS .. ON/100%/EMERG
R	● <b>IF SMOKE SOURCE IMMEDIATELY OBVIOUS, ACCESSIBLE, AND EXTINGUISHABLE :</b>
R	- FAULTY EQPT ..... ISOLATE
R	● <b>IF SMOKE SOURCE NOT IMMEDIATELY ISOLATED :</b>
R	- DIVERSION ..... INITIATE
R	- DESCENT (FL 100 or MEA, or minimum obstacle clearance altitude) .... INITIATE
R	● <b>AT ANY TIME of the procedure, if SMOKE/FUMES becomes the GREATEST THREAT :</b>
R	- SMOKE/FUMES REMOVAL ... CONSIDER
R	- ELEC EMER CONFIG ..... CONSIDER
R	<i>Refer to the end of the procedure to set ELEC EMER CONFIG</i>
R	● <b>At ANY TIME of the procedure, if situation becomes UNMANAGEABLE :</b>
R	- IMMEDIATE LANDING ..... CONSIDER

## SMOKE PROCEDURE LAYOUT

**Dense smoke** recommendations:

- **AT ANY TIME** of the procedure, if **SMOKE/FUMES** becomes the **GREATEST THREAT** :
  - SMOKE/FUMES REMOVAL ... CONSIDER
  - ELEC EMER CONFIG ..... CONSIDER  
*Refer to the end of the procedure to set ELEC EMER CONFIG*




# SMOKE PROCEDURE LAYOUT

## General **guidelines** to determine the smoke source:

*(available in FCOM Volume 3 but not in QRH)*



 • If smoke initially comes out of the **ventilation outlets** in the cockpit...  
- Suspect **AIR COND SMOKE**.  
(In addition, very shortly after, several SMOKE warnings (cargo, lavatory, avionics) will be triggered)

 • **AVIONICS SMOKE** warning with a piece of equipment declared faulty...  
- Suspect smoke from that piece of equipment.

 • **AVIONICS SMOKE** warning alone ...  
- Suspect AVIONICS SMOKE.

• Avionics or forward galley smoke may be smelt or may enter the cockpit before ECAM warning activation (A320 family only).

# SMOKE PROCEDURE LAYOUT

Specific actions:

## AIR COND SMOKE

### ■ IF AIR COND SMOKE SUSPECTED :

- APU BLEED ..... OFF
- BLOWER ..... AUTO
- EXTRACT ..... AUTO
- PACK 1 ..... OFF

### ● **If smoke continues :**

- PACK 1 ..... ON
- PACK 2 ..... OFF

### ● **If smoke still continues :**

- PACK 2 ..... ON
- BLOWER ..... OVRD
- EXTRACT ..... OVRD
- SMOKE/FUMES REMOVAL . CONSIDER

# SMOKE PROCEDURE LAYOUT

Specific actions:

## CAB EQUIPMENT SMOKE

- **IF CAB EQUIPMENT SMOKE SUSPECTED:**

- **If smoke continues :**

- EMER EXIT LIGHT ..... ON
- COMMERCIAL ..... OFF
- SMOKE DISSIPATION ..... CHECK
- FAULTY EQPT ..... SEARCH/ISOLATE

- **If smoke still continues or if faulty equipment confirmed isolated :**

- COMMERCIAL ..... NORM
- SMOKE/FUMES REMOVAL . CONSIDER

# SMOKE PROCEDURE LAYOUT

## Specific actions:

If smoke source cannot be determined or AVNCS/ELEC smoke suspected:

- SMOKE/FUMES/AVNCS SMOKE (CONT'D)**
- **IF SMOKE SOURCE CANNOT BE DETERMINED AND STILL CONTINUES OR AVNCS/ELECTRICAL SMOKE SUSPECTED :**
    - **Shed AC BUS 1 as follows :**
      - GEN 2 ..... CHECK ON
      - ELEC page ..... SELECT
      - BUS TIE ..... OFF
      - AC ESS FEED ..... ALTN
      - GEN 1 ..... OFF
      - SMOKE DISSIPATION ..... CHECK
    - **If smoke continues :**
      - GEN 1 ..... ON
      - AC ESS FEED ..... NORM
    - **Shed AC BUS 2 as follows :**
      - GEN 1 ..... CHECK ON
      - ELEC PAGE ..... SELECT
      - AC ESS FEED ..... CHECK NORM
      - BUS TIE ..... CHECK OFF
      - GEN 2 ..... OFF
      - SMOKE DISSIPATION ..... CHECK
    - **If smoke continues :**
      - GEN 2 ..... ON
      - BUS TIE ..... AUTO
  - SMOKE/FUMES REMOVAL ... CONSIDER
  - ELEC EMER CONFIG ..... CONSIDER

# SMOKE PROCEDURE LAYOUT

## How to set **ELEC EMER CONFIG**

### **TO SET ELEC EMER CONFIG**

- EMER ELEC GEN 1 LINE ..... OFF
- EMER ELEC PWR ..... MAN ON

### ● **WHEN EMER GEN AVAIL :**

- APU GEN ..... OFF
- GEN 2 ..... OFF

### **ELEC** **EMER CONFIG**

- APPLY ECAM PROCEDURE
- IF AVIONICS SMOKE ECAM NOT TRIGGERED DO NOT PERFORM THE GEN RESET

# SMOKE REMOVAL PROCEDURE

Smoke Removal without window opening

If cockpit window opening required ...

## SMOKE/FUMES REMOVAL

Use the smoke removal procedure if there is dense smoke, toxic fumes (smell), or if smoke generation cannot be stopped.

- R - EMER EXIT LIGHT ..... ON
- If fuel vapors :
  - CAB FANS ..... ON
  - PACK 1+2 ..... OFF
- If no fuel vapors :
  - CAB FANS ..... OFF
  - PACK FLOW ..... HI
  - LDG ELEV ..... 10000 FT/MEA
  - DESCENT (FL 100, or MEA, or minimum obstacle clearance altitude) ..... INITIATE
  - ATC ..... NOTIFY

R - SMOKE/FUMES/  
R AVNCS SMOKE PROC ..... CONTINUE

While descending, continue applying the appropriate steps of the SMOKE/FUMES/AVNCS SMOKE procedure depending on the suspected smoke source.

- At FL100 or MEA :
  - PACK 1+2 ..... OFF
  - MODE SEL ..... MAN
  - MAN V/S CTL ..... FULL UP
  - RAM AIR ..... ON

- If smoke persists, cockpit window opening :
  - MAX SPEED ..... 200 KT
  - COCKPIT DOOR ..... OPEN
  - HEADSETS ..... ON
  - PNF COCKPIT WINDOW ..... OPEN

- When window is open :
  - NON-AFFECTED PACK(s) ..... ON
  - VISUAL WARNINGS (noisy CKPT) ..... MONITOR
  - SMOKE/FUMES/ AVNCS SMOKE PROC ... CONTINUE



## CONCLUSION

**Apply the procedure** (regardless of whether a warning is triggered or not)

Apply the “**standard actions**”.

**Determine the smoke source.**

Depending on the smoke source, **apply the specific actions.**

**At any time, if necessary:**

**EMER EXIT Lights ON**

Descend to 10,000ft or MORA for **smoke removal.**

Set **ELEC EMER CONFIG.**

## General **guidelines** to determine the smoke source:

*(available in FCOM Volume 3 but not in QRH)*

### *Guidelines to determine smoke source :*

- If smoke initially comes out of the ventilation outlets, the crew may suspect AIR COND SMOKE. In addition, very shortly thereafter, several SMOKE warnings (cargo, lavatory, avionics) will be triggered. The displayed ECAM procedures must be applied.*
- Following an identified ENG or APU failure, smoke may emanate from the faulty item through the bleed system and be perceived in the cockpit, and/or in the cabin. In such a case, it will be recirculated throughout the aircraft, until it completely disappears from the air conditioning system.*
- If only the AVIONICS SMOKE warning is triggered, the crew may suspect avionics smoke.*
- If the smoke is detected while an equipment is declared faulty, the crew may suspect that smoke is coming from this equipment.*
- Avionics or forward galley smoke may be smelt, or may enter in the cockpit before ECAM warning activation.*