

**7.8 - ELECTRICAL SYSTEM** (Figures 7.8.1 and 7.8.5)

The airplane is fitted with a direct-current electrical system rated to 28 volts with negative pole at ground.

Airplane mains supply is obtained from various power supplies :

- an engine driven starter generator
- a stand-by generator driven by the engine through a belt
- a battery located in engine compartment
- a ground power receptacle located in engine compartment, on L.H. side. It is accessible from outside through a door.

Connection relays, main bus bar, generator regulation and protection systems and control logic systems are grouped in electrical power center attached to front baggage compartment upper section.

Indicating and checking warning lights are grouped on advisory panel.

**STARTER GENERATOR**

The starter generator is the main electrical power source. It only performs its generator function when starting sequence is completed.

Generator connection with main bus bar is controlled through "GENERATOR" selector set to "MAIN" position. It will be effective when connection conditions are met. Generator connection is indicated by "MAIN GEN" warning light extinguishing.

### **STAND-BY GENERATOR**

Stand-by generator supplies a 28-volt stand-by direct current which may be used in case of main generator failure.

Generator connection with main bus bar is controlled through "GENERATOR" selector set to "ST-BY", it will be effective when connection conditions are met.

**NOTE :**

*In order to prevent possible errors during flight, access to "ST-BY" position requires a double action from the pilot (pull to unlock).*

### **BATTERY**

The battery provides the power required for starting when no ground power unit is available and is a power supply source when engine driven generators are stopped.

The battery is always connected to "BAT BUS" bus bar except when CRASH lever is pulled down.

Battery connection to main bus bar is controlled through "SOURCE" selector set to "BAT" position.

"BAT OFF" warning light is illuminated when battery is isolated from the main bus and when main bus is supplied through another source.

### **GROUND POWER RECEPTACLE**

The ground power receptacle allows connection to a ground power unit. Ground power receptacle connection with main bus bar is controlled through "SOURCE" selector when set to "GPU" position, it will be effective when connection conditions are met.

**NOTE :**

*Ground power receptacle has priority on other generators.*

Ground power receptacle door opening is indicated by "GPU" warning light illumination.

INTENTIONALLY LEFT BLANK

## DISTRIBUTION

Airplane electrical systems are connected to "BUS" bars and protected by circuit breakers located on L.H. side panel, near the pilot (See Figure 7.8.3) or on R.H. side panel, if "pilot" door installed (See Figure 7.8.3A). In case of overload of a system, the circuit breaker triggers and switches the system off. Allow it to cool for about three minutes, then the circuit breaker may be reengaged (pressed down). Some systems are equipped with "pull off" type circuit breakers which allow the pilot to insulate, if necessary, the corresponding equipment.

"BUS 1", "BUS 2" and "BUS 3" bus bars are directly connected to main bus bar and protected by fuses located in electrical power center.

"ESS 1" and "ESS 2" essential bus bars are connected to main bus bar through "ESS BUS TIE" selector set to "NORM" position. "ESS BUS TIE" selector is attached to circuit breaker panel, "NORM" position is protected and locked by a cover. Common power supply to both essential bus bars is protected by a fuse, each bar being individually protected by a circuit breaker.

"BUS BAT" bar is directly connected to the battery, it is protected by a fuse located in electrical power center.

### NOTE :

*The electrical distribution of bus bars is described in Figure 7.8.2.*

## EMERGENCY USE

With both generators de-activated in flight, it is still possible to use battery power to supply all airplane systems maintaining "SOURCE" selector on "BAT" position.

In order to save battery power, it is possible to shed the charges which are not essential for flight safety, for that set :

- "ESS BUS TIE" selector to "EMER" position

In this configuration, only "ESS 1", "ESS 2" and "BAT BUS" bars are supplied.

### NOTE :

*Supplying "BUS 1", "BUS 2" and "BUS 3" bars is always possible, resetting temporarily "ESS BUS TIE" selector to "NORM" position.*






Figure 7.8.1 - ELECTRICAL DIAGRAM



14246000AAA.C/M/A8000

Figure 7.8.2 (1/2) - ELECTRICAL DISTRIBUTION OF BUS BARS




I4246000AAACMA8100

Figure 7.8.2 (2/2) - ELECTRICAL DISTRIBUTION OF BUS BARS



<b>AP / TRIMS</b>	AP & trims general protec.	<b>FUEL GAGE 1</b>	L.H gage protection
<b>RUD TRIM</b>	Rudder trim protection	<b>FUEL GAGE 2</b>	R.H gage protection
<b>AIL TRIM</b>	Aileron trim protection	<b>FUEL SEL</b>	Timer protection
<b>PITCH TRIM</b>	Pitch trim protection	<b>AUX BP</b>	Fuel pump protection
<b>FLAPS</b>	Flaps protection	<b>ENGINE INDIC 1</b>	Power plant cont. protec. : Oil temp. & pres., torque, propeller
<b>LDG GR</b>	Landing gear general protec.	<b>ENGINE INDIC 2</b>	Power plant cont. protection : Ng, flowmeter & ITT
<b>ESS BUS TIE</b>	Essential bus NORM & EMER switch	<b>IGNIT</b>	Power plant ignit. protection
<b>PITOT 1 HTR</b>	Pitot 1 deicing protection	<b>CABIN BLEED AIR COND</b>	Cabin air bleed valve protec. Cabin ventilation and vapor cycle cooling system protec.
<b>PITOT 2 &amp; STALL HTR</b>	Pitot 2 and stall warning deicing protection	<b>MEMORY &amp; CLOCK ACCESS</b>	Stop watch and flowmeter protec. Cabin lightings & access door closing geared motor protec.
<b>INERT SEP</b>	Inertial separator protection	<b>EHSI</b>	EHSI protection
<b>LW/S DE ICE</b>	L.H. windshield deicing protection	<b>EADI</b>	EADI protection
<b>RW/S DE ICE</b>	R.H. windshield deicing protection	<b>GYRO</b>	EFIS static converter protection
<b>PROP DE ICE</b>	Propeller deicing protection	<b>RMI</b>	RMI 1 protection
<b>AIRFRAME DE ICE</b>	Empennage and wing leading edges deicing protection	<b>ADI 2</b>	ADI No. 2 protection
<b>AUDIO CD</b>	CD reader protection (if installed)	<b>RMI 2</b>	RMI 2 protection
<b>FLAPS SIG</b>	Flaps signalization protec.	<b>HSI 2</b>	HSI 2 protection
<b>LDG GR CONT</b>	Landing gear control protection	<b>ELT</b>	Emergency beacon protection
<b>LDG GR SIG</b>	Landing gear signalization protection	<b>28VDC PLUGS</b>	28 volts plugs protection
<b>AP DISC</b>	Trim and AP cont. protection	<b>PHONE+MKR</b>	Reception line and loudspeaker + MKR protection
<b>AP ALERT</b>	Trim and AP audio signalization protection	<b>COM NAV 1</b>	HONEYW. COM NAV 1 protec. (if installed)
<b>AP ALT SEL</b>	Altitude selector protection	<b>NAV GPS 1</b>	GARMIN NAV GPS 1 protec. (if installed)
<b>ESS BUS 1</b>	Essential bus 1 circuit protection	<b>GND CLR</b>	Ground communication protec.
<b>ESS BUS 2</b>	Essential bus 2 circuit protection	<b>XPDR 2</b>	Transponder 2 protection
<b>ADVISORY 1</b>	Visual warnings protection	<b>COM NAV 2</b>	HONEYW. COM NAV 2 protec. (if installed)
<b>ADVISORY 2</b>	Visual warnings protection	<b>NAV GPS 2</b>	GARMIN NAV GPS 2 protec. (if installed)
<b>AUDIO WARN</b>	Audio warnings protection	<b>ENCOD ALTI</b>	Encoding altimeter protection
<b>L LDG</b>	L.H. landing light protection	<b>XPDR</b>	Transponder 1 protection
<b>TAXI</b>	Taxi light protection	<b>RADIO ALTI</b>	RADIO ALTI protection
<b>R LDG</b>	R.H. landing light protection	<b>RADIO + FAN</b>	Radio ventilation + radio master protection
<b>NAV</b>	Navigation lights protection	<b>ADF</b>	ADF protection
<b>STROBE</b>	Strobe lights protection	<b>DME</b>	DME protection
<b>ICE</b>	L.H. wing leading edge light.	<b>TAS/TAWS</b>	TAS/TAWS protec. (if installed)
<b>LIGHT</b>	and lighting test protection	<b>STORM</b>	Stormscope protection
<b>PULSE</b>	Pulse lite system (if installed)	<b>WSR</b>	Weather radar protection
<b>SYST</b>	protection	<b>MFD</b>	Multi-function display protec.
<b>INSTR</b>	Instruments lighting protec.	<b>GPS</b>	HONEY. GPS protec. (if insta.)
<b>PANEL NORM</b>	Instrument panel normal lighting protection	<b>COM 1</b>	VHF 1 protection (if installed)
<b>PANEL EMER</b>	Instrument panel emergency lighting protection	<b>COM 2</b>	VHF 2 & radio protection (if installed)
<b>CABIN</b>	Passenger's reading lamps protection		

Figure 7.8.3 (1/3) - CIRCUIT BREAKER PANEL (Typical arrangement)






14255004AAAAGMA18103

-  Disjoncteur déclenchable  
"PULL-OFF" type circuit breaker
-  Disjoncteur non déclenchable  
Circuit breaker which cannot be pulled off



**NOTE :**

If an additional equipment is installed, its circuit breaker is installed on a free location.

Figure 7.8.3 (2/3) - CIRCUIT BREAKER PANEL  
("HONEYWELL" typical arrangement)



14250044AAAGMA18203

-  Disjoncteur déclenchable  
"PULL-OFF" type circuit breaker
-  Disjoncteur non déclenchable  
Circuit breaker which cannot be pulled off


**NOTE :**  
If an additional equipment is installed, its circuit breaker is installed on a free location.

Figure 7.8.3 (3/3) - CIRCUIT BREAKER PANEL  
("GARMIN" typical arrangement)

INTENTIONALLY LEFT BLANK

<b>ESS BUS TIE</b>	Essential bus NORM & EMER switch	<b>PULSE SYST</b>	Pulse lite system (if installed) protection
<b>LDG GR</b>	LDG general protection	<b>ICE LIGHT</b>	L.H. wing leading edge lighting and lighting test protection
<b>FLAPS</b>	Flaps protection	<b>STROBE</b>	Strobe lights protection
<b>PITCH TRIM</b>	Pitch trim protection	<b>L LDG</b>	L.H. landing light protection
<b>AIL TRIM</b>	Aileron trim protection	<b>TAXI</b>	Taxi light protection
<b>RUD TRIM</b>	Rudder trim protection	<b>R LDG</b>	R.H. landing light protection
<b>AP / TRIMS</b>	AP & trims general protec.	<b>NAV INSTR</b>	Navigation lights protection Instruments lighting protec.
<b>ESS BUS 1</b>	Essential bus 1 circuit protection	<b>PANEL NORM</b>	Instrument panel normal lighting protection
<b>ESS BUS 2</b>	Essential bus 2 circuit protection	<b>PANEL EMER</b>	Instrument panel emergency lighting protection
<b>ADVISORY 1</b>	Visual warnings protection	<b>CABIN</b>	Passenger's reading lamps protection
<b>ADVISORY 2</b>	Visual warnings protection	<b>ACCESS</b>	Cabin lightings & access door closing geared motor protec. Stop watch and flowmeter protec.
<b>AUDIO WARN</b>	Audio warnings protection	<b>MEMORY &amp; CLOCK</b>	
<b>FLAPS SIG</b>	Flaps signalization protec.	<b>ELT</b>	Emergency beacon protection
<b>LDG GR CONT</b>	Landing gear control protection	<b>EHSI</b>	EHSI protection
<b>LDG GR SIG</b>	Landing gear signalization protection	<b>EADI</b>	EADI protection
<b>AP DISC</b>	Trim and AP cont. protection	<b>GYRO</b>	EFIS static converter protection
<b>AP ALERT</b>	Trim and AP audio signalization protection	<b>RMI</b>	RMI 1 protection
<b>AP ALT SEL</b>	Altitude selector protection	<b>ADI 2</b>	ADI No. 2 protection
<b>AUDIO CD</b>	CD reader protection (if installed)	<b>RMI 2</b>	RMI 2 protection
<b>PITOT 1 HTR</b>	Pitot 1 deicing protection	<b>HSI 2</b>	HSI 2 protection
<b>PITOT 2 &amp; STALL HTR</b>	Pitot 2 and stall warning deicing protection	<b>RADIO ALTI</b>	RADIO ALTI protection
<b>INERT SEP</b>	Inertial separator protection	<b>28VDC PLUGS</b>	28 volts plugs protection
<b>LW/S DE ICE</b>	L.H. windshield deicing protection	<b>PHONE+MKR</b>	Reception line and loudspeaker + MKR protection
<b>RW/S DE ICE</b>	R.H. windshield deicing protection	<b>COM NAV 1</b>	HONEYW. COM NAV 1 protec. (if installed)
<b>PROP DE ICE</b>	Propeller deicing protection	<b>NAV GPS 1</b>	GARMIN NAV GPS 1 protec. (if installed)
<b>AIRFRAME DE ICE</b>	Empennage and wing leading edges deicing protection	<b>GND CLR</b>	Ground communication protec.
<b>ENGINE INDIC 1</b>	Power plant contr. protec. : Oil T° & pres., torque, propel.	<b>XPDR 2</b>	Transponder 2 protection
<b>ENGINE INDIC 2</b>	Power plant contr. protec. : Ng, flowmeter & ITT	<b>COM NAV 2</b>	HONEYW. COM NAV 2 protec. (if installed)
<b>IGNIT</b>	Power plant ignit. protection	<b>NAV GPS 2</b>	GARMIN NAV GPS 2 protec. (if installed)
<b>CABIN BLEED AIR COND</b>	Cabin air bleed valve protec. Cabin ventilat. and vapor cycle cooling system protec.	<b>ENCOD ALTI</b>	Encoding altimeter protection
<b>FUEL GAGE 1</b>	L.H gage protection	<b>XPDR GPS</b>	Transponder 1 protection HONEYW. GPS protection (if installed)
<b>FUEL GAGE 2</b>	R.H gage protection	<b>COM 1</b>	VHF 1 protection (if installed)
<b>FUEL SEL</b>	Timer protection	<b>COM 2</b>	VHF 2 & radio (if insta.) protec.
<b>AUX BP</b>	Fuel pump protection	<b>ADF</b>	ADF protection
		<b>DME</b>	DME protection
		<b>TAS/TAWS</b>	TAS/TAWS (if installed) protec.
		<b>STORM</b>	Stormscope protection
		<b>WSR</b>	Weather radar protection
		<b>MFD</b>	Multi-function display protection
		<b>RADIO+ FAN</b>	Radio ventilation + radio master protection

Figure 7.8.3A (1/3) - CIRCUIT BREAKER PANEL (Typical arrangement)



14255004AAAGMA18003



Disjoncteur déclenchable  
"PULL-OFF" type circuit breaker




Disjoncteur non déclenchable  
Circuit breaker which cannot be pulled off



**NOTE :**

If an additional equipment is installed, its circuit breaker is installed on a free location.

Figure 7.8.3A (2/3) - CIRCUIT BREAKER PANEL  
("HONEYWELL" typical arrangement)



1425004AAAGMA8303

-  Disjoncteur déclenchable  
"PULL-OFF" type circuit breaker
-  Disjoncteur non déclenchable  
Circuit breaker which cannot be pulled off

**NOTE :**  
If an additional equipment is installed, its circuit breaker is installed on a free location.

Figure 7.8.3A (3/3) – CIRCUIT BREAKER PANEL  
("GARMIN" typical arrangement)

**INDICATING** (Figure 7.8.4)

Electrical system indicating consists of a voltmeter and an ammeter located on the upper panel, as well as warning lights grouped on advisory panel.

The **voltmeter** indicates the voltage with generator connected to main bus bar. When the starter generator or stand-by generator are operating normally, the voltmeter needle will be in green sector.

The **ammeter**, graduated from - 200 to + 200 amperes, indicates the battery charge and discharge. The needle indicates a positive value when battery and starter generator (or stand-by generator) are connected to main bus bar.

Indications provided by warning light illumination are as follows :

- "BAT OVHT" : Overheat inside the battery (if Cadmium-Nickel battery installed)
- "BAT OFF" : Battery is not connected to main bus bar and the latter is supplied by another power source
- "MAIN GEN" : Starter generator is not connected to main bus bar
- "LO VOLT" : Battery voltage is below the minimum value and main bus bar is supplied
- "GPU" : Ground power receptacle access door is not closed

Moreover, the indicating system may be completed by a battery temperature indicator located on the R.H. lower part of the R.H. instrument panel. This indicator is connected to a probe installed on the battery. A "BAT TEMP TEST" push-button located near the indicator allows to test the illumination of the "BAT OVHT" warning light and to check simultaneously, on the indicator, the increase of the indicated temperature.

**PROTECTION - SAFETY** (Figure 7.8.5)

The electrical power center provides systems protection in case of :


- overvoltage coming from the starter generator, the stand-by generator or the ground power receptacle
- short-circuit in starter generator feeder
- starter generator undervoltage

In case of disconnection of starter generator or stand-by generator following a failure, it is possible to re-activate the system by pressing on "MAIN" or "ST-BY" knob of "GENERATOR RESET".

A **crash lever** located on upper panel center part allows isolating simultaneously "BUS BAT" bar and setting to "OFF", "SOURCE" and "GENERATOR" selectors when lowered. All bus bars are isolated from generators.



- 1) Ammeter
- 2) Voltmeter
- 3) General flashing red and amber warning lights
- 4) Electric system warning lights on the "ADVISORY PANEL"
- 5) Battery temperature indicator (if installed)
- 6) "BAT TEMP TEST" push-button (if installed)



I4251000AAAKMA8002






Figure 7.8.4 (1/2) - INDICATING



14315001AAAABMA8103

Figure 7.8.4 (2/2) - INDICATING



- 1) "MAIN" reset knob
- 2) "ST-BY" reset knob
- 3) Crash lever
- 4) "SOURCE" selector
- 5) "GENERATOR" selector

I424000AAAAEMA8200




Figure 7.8.5 - ELECTRICAL CONTROL

**EXTERIOR LIGHTING** (Figure 7.8.6)

The airplane is equipped with two navigation lights, two strobe lights, two landing lights, a taxi light, a wing leading edge icing inspection light.

A "LTS TEST" test-knob located above lights switches allows checking proper operation of warning lights ; their brightness may be dimmed by main "DIM" switch on advisory panel.

**Landing lights**

Landing lights are located at each wing tip and located in leading edges. Lights illumination is controlled by "L. LDG" and "R. LDG" switches located on upper panel. A warning light is incorporated in each switch to indicate proper operation of used landing light.

The Pulse lite system (if installed) enables the pilot to control landing light flashing to be seen by the control tower or in heavy traffic areas.

**Taxi light**

The taxi light is attached to the nose gear, it is controlled by "TAXI" switch located on upper panel. A warning light is incorporated in this switch to indicate proper operation of used light.

**Navigation lights and strobe lights**

Navigation lights and strobe lights are installed on wing tips. They are controlled by "NAV" and "STROBE" switches located on upper panel.

**NOTE :**

*By night, do not use anticollision lights in fog, clouds or mist as light beam reflexion may lead to dizziness and loss of sense of orientation.*

**Leading edge icing inspection light**

The leading edge icing inspection light is installed on fuselage L.H. side, its beam illuminates the wing leading edge. It is controlled by the "ICE LIGHT" switch installed on "DE-ICE SYSTEM" panel (Figure 7.13.1).

**FWD compartment light**

The dome light of the FWD compartment has two positions :


- the first allows automatic illumination via the switch located in the upper section of the door frame,
- the second maintains the dome light permanently off regardless of the door position.

**Fuel unit compartment light**

The lighting of the fuel unit compartment allows improving the visibility of the clogging indicator by pressing the push-button located besides the inspection door.

- 1) L.H. landing light switch
- 2) Test knob (test light integrated to switches)
- 3) Taxi light switch
- 4) R.H. landing light switch
- 5) Navigation lights switch
- 6) Strobe lights switch
- 7) Pulse lite system switch (if installed)

Figure 7.8.6 (1/2) - EXTERNAL LIGHTING CONTROLS



14334000AAAAA/A8100




Figure 7.8.6 (2/2) - EXTERNAL LIGHTING CONTROLS

## **INTERIOR LIGHTING (Figure 7.8.7)**

Interior lighting consists of access, cabin, instrument panel, instruments, baggage compartment and emergency lighting.

### **Access lighting**

Access lighting consists of two floodlights located on the ceiling upholstery (one at the level of the access door, the other at the level of the storage cabinet) and the L.H. dome light of baggage compartment. "ACCESS" push-button on "INT LIGHTS" panel and the push-button located on access door rear frame control these 3 lights via a delayed breaker.

If the CRASH lever is down, access lighting is automatically cut out after 3 minutes.

If the CRASH lever is up, there is no access lighting automatic cut out.

### **Cabin lighting**

Cabin lighting consists of two swiveling floodlights for front seats, six individual floodlights for rear passenger seats and the baggage compartment R.H. dome light. Each floodlight is controlled by a switch located on side upholstery strip. The floodlight above the table is controlled by two switches which are two-way switches type. The pilot can switch off the cabin floodlights and the baggage compartment dome light with the "CABIN" switch.

### **Instrument panel lighting**

Instrument panel lighting is controlled by the "PANEL" rheostat located on "INT. LIGHTS" panel. This lighting consists of visor lighting and the two postlights located on the upper duct (forward of emergency floodlights).

### **Instruments and radio equipment lighting**

The lighting, controlled by the "INSTR" rheostat located on "INT. LIGHTS" panel is integrated in instruments and radio equipment.

#### **NOTE :**

*"PANEL" and "INSTR" rheostats control lighting operation and intensity. Clockwise rotation of control knob allows changing from "OFF" position to maximum lighting. Counterclockwise rotation reduces lighting to minimum brightness.*



**Emergency lighting**

Emergency lighting consists of two swiveling floodlights located on the upper duct above front seats. It illuminates instrument panel assembly in case of visor lighting and / or instrument integrated lighting failure.




The rheostat located near R.H. floodlight controls emergency lighting operation and intensity. Forward rotation of control knob allows changing from "OFF" position to minimum lighting then increasing lighting to maximum brightness.

**Map reading light illumination**

The illumination of the map reading lights located on control wheels is controlled by the switch (rheostat) located on each light.

- 1) Instrument lighting switch (rheostat)
- 2) Instrument panel lighting switch (rheostat)
- 3) Cabin lighting switch (rear seats reading light)
- 4) Access door, baggage compartment and FWD dome light (delayed breaker) push-button
- 5) Emergency lighting switch (rheostat)

Figure 7.8.7 (1/2) - INTERNAL LIGHTING CONTROLS



14332001AAAFMA8102

Figure 7.8.7 (2/2) - INTERNAL LIGHTING CONTROLS

INTENTIONALLY LEFT BLANK